

## **Portable Keyboard Basic's**

### **Selecting a sound**

1. Push Tone or Voice (large button)
2. Locate Tone or Voice list at top of instrument
3. Select the number next to selected tone section
  4. Type number on keypad
5. Use + and – to find specific instrument in that tone group  
(see owners manual for specific tones listings between sections)

### **Selecting a rhythm and style**

1. Push Style or Rhythm (large button)
2. Locate Style or Rhythm list at top of instrument
3. Select the number next to the rhythm category
  4. Type number on keypad
5. Use + and – button for specific rhythms and styles in that genre.  
(see owners manuals for specifics)

### **Splitting the keyboard to play chords with accompaniment and rhythms**

1. Set up the rhythm or styles listed above
2. push Accomp. Button (close to Start/stop)
  3. push sync start
4. Play a chord (a broken rhythmic chord will sound)
  5. Select a voice for the melody and play